

time with the amount of power a facility would have generated if it had run at full capacity) no earlier than in 5-year intervals from the most recent year that BOEM adjusts the capacity factor.

(iii) The process by which BOEM will adjust the capacity factor, including any calculations (incorporating an average capacity factor reflecting actual operating experience), will be specified in the lease. The operator or lessee may request review and adjustment of the capacity factor under § 585.510.

(4) Ten days after the anniversary date of when you began to commercially generate electricity, you must submit to BOEM documentation of the gross annual generation of electricity produced by the generating facility on the lease. You must use the same information collection form as authorized by the EIA for this information.

(5) For the nameplate capacity “M,” BOEM will use the total installed capacity of the equipment you install, as specified in your approved COP.

(d) You must submit all operating fee payments to BOEM in accordance with the provisions under 30 CFR 1218.51.

(e) BOEM will establish the operating fee in the Final Sale Notice or in the lease on a case-by-case basis for:

(1) Activities that do not relate to the generation of electricity (e.g., hydrogen production), and

(2) Leases issued for hydrokinetic activities requiring a FERC license.

**§ 585.507 What rent payments must I pay on a project easement?**

(a) You must pay ONRR, under the regulations at 30 CFR part 1218, a rent fee for your project easement of \$5 per acre, subject to a minimum of \$450 per year, unless specified otherwise in the Final Sale Notice or lease:

(1) The size of the project easement area for a cable or a pipeline is the full length of the corridor and a width of 200 feet (61 meters), centered on the cable or pipeline; and

(2) The size of a project easement area for an accessory platform is limited to the aerial extent of anchor chains and other facilities and devices associated with the accessory.

(b) You must commence rent payments for your project easement upon our approval of your COP or GAP:

(1) You must make the first rent payment when the operations term begins, as provided in § 585.500;

(2) You must submit all subsequent rent payments in accordance with the regulations at 30 CFR 1218.51; and

(3) You must continue to pay annual rent for your project easement until your lease is terminated.

**§ 585.508 What rent payments must I pay on ROW grants or RUE grants associated with renewable energy projects?**

(a) For each ROW grant BOEM approves under subpart C of this part, you must pay ONRR, under the regulations at 30 CFR part 1218, an annual rent as follows, unless specified otherwise in the Final Sale Notice:

(1) A fee of \$70 for each nautical mile or part of a nautical mile of the OCS that your ROW crosses; and

(2) An additional \$5 per acre, subject to a minimum of \$450 for use of the entire affected area, if you hold a ROW grant that includes a site outside the corridor of a 200-foot width (61 meters), centered on the cable or pipeline. The affected area includes the areal extent of anchor chains, risers, and other devices associated with a site outside the corridor.

(b) For each RUE grant BOEM approves under subpart C of this part, you must pay ONRR, under the regulations at 30 CFR part 1218, a rent of:

(1) \$5 per acre per year; or

(2) A minimum of \$450 per year.

(c) You must make the rent payments required by paragraphs (a) and (b) of this section on:

(1) An annual basis;

(2) For a 5-year period; or

(3) For multiples of 5 years.

(d) You must make the first annual rent payment upon approval of your ROW grant or RUE grant request, as provided in § 585.500, and all subsequent rent payments to ONRR in accordance with the regulations at 30 CFR 1218.51.

**§ 585.509 Who is responsible for submitting lease or grant payments to BOEM?**

(a) For each lease, ROW grant, or RUE grant issued under this part, you